



wege entstehen, indem wir sie gehen
paths emerge in that we walk them

Wegener Center
www.wegcenter.at



ACCURATE: Multi Species Retrieval (MSR) from Combined IR-Laser and Microwave Occultation Data

V. Proschek, G. Kirchengast, S. Schweitzer, and J. Fritzer

Wegener Center for Climate and Global Change (WegCenter) and
Institute for Geophysics, Astrophysics and Meteorology / Inst. of Physics,
University of Graz, Graz, Austria

funded by 



OPAC 2010 International Workshop on Occultations for Probing Atmosphere and Climate, Graz, Austria



- 1 Overview
 - LMIO-Scheme
 - Atmospheric Effects

- 2 Retrieval and Example Results
 - Scheme
 - Starting Parameter
 - Single-Line Trace Species Retrieval SSR
 - Multi-Line Trace Species Retrieval MSR

- 3 Summary and Conclusions




Figure: LMIO Scheme

LMO: 9-23 GHz, 175-200 GHz

LIO: 2-2.5 μm

- Refraction
- Rayleigh scattering
- Scintillation
- Solar scattering into the receiver
- Doppler shift on intensities due to wind
- Clouds, except very thin cirrus clouds, block the IR signals

Effect of interest:

- Absorption by molecules:
 - Greenhouse gases (GHGs)
{ H_2O , CO_2 , CH_4 , N_2O , O_3 , CO }
 - Isotopes
{ $^{13}\text{CO}_2$, C^{18}OO , HDO , H_2^{18}O }




Figure: Retrieval Scheme

LMO:

- Tangent point height $\vec{z}_{mw}(\vec{t})$
- Temperature $\vec{T}(\vec{z}_{mw})$
- Pressure $\vec{p}(\vec{z}_{mw})$
- Humidity $\vec{q}(\vec{z}_{mw})$
- Positions $\vec{x}(\vec{t})$ of transmitter (T_x) and receiver (R_x)

LIO:





Figure: Intensity profile for the absorption and reference channel of $^{12}\text{CO}_2$

EXTERNAL:

- Initialize/background GHG profile(s)

- 1 Tangent point height calculation for the IR signal time series
- 2 Defocusing correction of the raw transmission
- 3 Target species transmission extraction:
 - a) Subtraction of reference- from absorption channel transmission
 - b) Foreign/background species absorption correction with background GHG profiles
- 4 Calculate the absorption coefficient from the GHG transmission
- 5 Calculate the volume mixing ratio of the GHG target species



Initializing parameter for the iteration process of $z_{ir}(t)$:

- n_{ir} refractive index (*Edlen-type formula*) and a_{ir} impact parameter on $z_{mw}(t)$ -grid:

$$n_{ir}(z_{mw}) \propto a_{ir}(z_{mw}) \propto \text{Const}(\nu) \cdot \frac{p(z_{mw})}{T(z_{mw})} \quad (1)$$

- α_{ir} bending angle on $a_{ir}(z_{mw})$ -grid:

$$\alpha_{ir}(a_{ir}) = 2 \cdot a_{ir} \int_{r_{mw}}^{\infty} \frac{1}{\sqrt{r^2 n_{ir}^2 - a_{ir}^2}} \frac{d \ln(n_{ir})}{dr} dr \quad (2)$$

- α_k geometric bending angle relation as initialization profile at every grid level with $a_{k=0} = a_{ir}$:

$$\alpha_k(a_k) = \theta - \arccos\left(\frac{a_k}{r_{Rx}}\right) - \arccos\left(\frac{a_k}{r_{Tx}}\right) \quad (3)$$

- θ ... Opening angle between T_x and R_x
- r_{mw} ... Distance from center of curvature to the tangent point height level
- r_{Rx} ... Distance from center of curvature to the R_x
- r_{Tx} ... Distance from center of curvature to the T_x

Iteration process of the tangent point height of the IR signal ($z_{ir}(t)$):

- Newton iteration:

$$a_{k+1} = a_k + \frac{(\alpha_k - \alpha_{ir})}{\left(\frac{d\alpha_k}{da_k}\right)} \quad (4)$$

- Interpolation of α_{ir} to the new a_{k+1}
- Calculation of the new α_{k+1} with equation (3)
- Convergence of $\Delta a_{k+1} = (a_{k+1} - a_k) < 1 \text{ m}$
- Calculation of the tangent point height $z_{ir}(t)$


$$z_{ir}(t) = \frac{a_{ir}(t)}{n_{ir}(t)} - R_C \quad (5)$$

R_C ... Radius of curvature

After step 2. defocusing and spreading correction:

a) Subtraction of the **reference-** from the **absorption** channel transmission to cancel out broadband effects:

- Solar scattering into Rx
- Scintillation
- Aerosol extinction
- Very thin cirrus cloud extinction



$$\Delta Tr_{\text{abs,ref}}(z_{\text{ir}}) = Tr_{\text{abs}}(z_{\text{ir}}) - Tr_{\text{ref}}(z_{\text{ir}}) \quad (6)$$

Figure: Transmission profile for the absorption and reference channel of $^{12}\text{CO}_2$

$\Delta Tr_{\text{abs,ref}}$... Differential transmission

Tr_{abs} ... Transmission of the absorption channel

Tr_{ref} ... Transmission of the reference channel

b) Correction due to modeled foreign/background species transmission using the **initialized/background GHG** profile:

$$Tr_{GHG}(z_{ir}) = \Delta Tr_{abs,ref}(z_{ir}) - (Tr_{bgr,abs}(z_{ir}) - Tr_{bgr,ref}(z_{ir})) \quad (7)$$





Figure: Transmission loss spectra (total, $^{12}\text{CO}_2$ only) and absorption- and reference channel

Figure: Transmission profile for the pure absorption by the target species $^{12}\text{CO}_2$

$Tr_{bgr,abs/ref}$... Transmission of the foreign species of the absorption/reference channel calculated by model (RFM)
 Tr_{GHG} ... Transmission of the target greenhouse gas

Abel Transform of the transmission Tr_{GHG} into the absorption coefficient α_{ir} :

$$\kappa_{\text{GHG}}(a_{ir,j}) = \frac{1}{\pi} \frac{da_{ir}}{dr_{ir}} \bigg|_{a_{ir}=a_{ir,j}} \int_{a_{ir,j}}^{\infty} \frac{1}{\sqrt{a_{ir}^2 - a_{ir,j}^2}} \frac{d \ln (Tr_{\text{GHG}}(a_{ir}))}{da_{ir}} da_{ir} \quad (8)$$





Figure: Transmission profile for $^{12}\text{CO}_2$

Figure: Abs. coeff. profile for $^{12}\text{CO}_2$

Conversion of the absorption coefficient $\kappa_{\text{GHG}}(z_{\text{ir}})$ into the **volume mixing ratio** $\chi_{\text{GHG}}(z_{\text{ir}})$ with the modeled species cross-section $\sigma_{\text{GHG}}(z_{\text{ir}})$

$$\chi_{\text{GHG}}(z_{\text{ir},j}) \propto \frac{\kappa_{\text{GHG}}(a_{\text{ir},j})}{\sigma_{\text{GHG}}(a_{\text{ir},j})} \quad (9)$$





Figure: Relative volume mixing ratio error of $^{12}\text{CO}_2$ in %

κ ... Absorption coefficient

σ ... Cross section computed by RFM with HITRAN database using LMO T, p

χ ... Volume mixing ratio




- 1 Loop over a defined order of trace species for sensible step-wise update of the initialize/background GHGs
- 2 Combination of ^{13}C isotope profiles and $\text{H}_2\text{O}(1-4)$ profiles
- 3 Iteration loop over the whole order of trace species sequence to guarantee convergence to the pure measurement-retrieved VMR profiles
- 4 Update of the initialize/background GHG profiles after every single GHG retrieval step


Consecutive order of retrieved single-line trace species:

{ $^{14}\text{N}_2\text{O}$, $^{12}\text{CH}_4$, $^{13}\text{CO}_2$, C^{18}OO , $\text{H}_2\text{O}(1-4)$, $^{12}\text{CO}_2$, HDO , H_2^{18}O , ^{12}CO , $^{16}\text{O}_3$ }





Correct CO_2
initialized/background GHG
profile for H_2O ret.:







Zero CO_2
initialized/background GHG
profile for H_2O ret.:



- $^{13}\text{CO}_2$ and $^{12}\text{CO}_2$ absorption lines
- each sensitive at all heights, but somewhat different
- combined with static inverse-variance weighting




- 4 H₂O absorption lines
- sensitive to different height ranges
- combined by dynamic inverse-variance weighting




Modified values of
initialized GHG profile:
{H₂O, CO₂, O₃} = 0 [ppmv]

1 Basic run




Modified values of
initialized GHG profile:
{H₂O, CO₂, O₃} = 0 [ppmv]

- 1 Basic run
- 2 First iteration run



Modified values of
initialized GHG profile:
{H₂O, CO₂, O₃} = 0 [ppmv]

- 1 Basic run
- 2 First iteration run
- 3 Second iteration run (Control run)



- Single Species Retrieval (SSR):
 - Core part of the whole retrieval process.
 - Reference obs system, since no external information dependence except the initialize/background GHG profiles
 - Algorithm of the GHG retrieval performs in a robust way and leads to accuracies of 1–4 % (monthly means expected < 0.15–0.5 %).
- Multi Species Retrieval (MSR):
 - Even with poor (zero) initial/background GHG profiles quick convergence to purely measurement-derived values; order of GHG sequence important as every next GHG already benefits from retrieval update of previous one.
 - Accurate retrieval possible in clear, aerosol-laden and turbulent air, also very thin cirrus clouds do not hinder a retrieval process (dedicated cloudy-air retrieval is next step).
 - Benefit due to combination of H₂O absorption and CO₂ isotope profiles; composite profiles.



Thank you for your attention!